

Swing wood back lounge chair, Swing upholstered lounge chair



Swing wood back lounge chair

I-145 アームチェア

W630×D575×H760×SH431×AH599

	背: <u>ブナ</u>	背: <u>ウォールナット</u>
	脚: <u>ブナ</u>	脚: <u>ウォールナット</u>
F1	198,000	209,000
F2	209,000	220,000
L1	242,000	253,000
L2	253,000	264,000



Swing upholstered lounge chair

I-146 アームチェア

W630×D575×H760×SH431×AH599

	背: <u>張り込み</u>	背: <u>張り込み</u>
	脚: <u>ブナ</u>	脚: <u>ウォールナット</u>
F1	176,000	198,000
F2	198,000	220,000
L1	286,000	308,000
L2	308,000	330,000



F1  
ストランド 00



F1  
ストランド 75



F1  
ストランド 77



L2  
スムーズ 40110



L2  
スムーズ 40109




L2  
スムーズ 40106



L2  
スムーズ 40108



L2  
スムーズ 40105



L2  
スムーズ 40104



L2  
スムーズ 40103



L2  
スムーズ 40107



L2  
スムーズ 40102



L2  
スムーズ 40101



ブナ  
ナチュラルホワイト



ブナ  
スノーホワイト



ブナ  
ミディアムグレー



ブナ  
チャコールグレー



ウォールナット  
クリア