

Dance, Dance Dance



Dance

IP-121 side chair

W506 × D519 × H764 × SH422

Beech	Walnut
700,00	830,00



Dance Dance

IP-122 armchair

W513 × D519 × H764 × SH422 × AH601

Beech	Walnut
830,00	960,00



Dance

IP-121F side chair

W506 × D519 × H764 × SH422

Upholstered	
F1	890,00
F2	960,00
L1	1.090,00
L2	1.180,00



Dance Dance


IP-122F armchair

W513 × D519 × H764 × SH422 × AH601

Upholstered	
F1	1.020,00
F2	1.090,00
L1	1.220,00
L2	1.300,00




Beech
Natural white




Beech
Snow white



Beech
Medium grey



Beech
Charcoal grey



Walnut
Clear



L1
Emboss 40202



L1
Emboss 40242



L1
Emboss 40243



L1
Emboss 40204



L1
Emboss 40205



L1
Emboss 40206




L1
Emboss 40209



L1
Emboss 40210



L1
Emboss 40215



L1
Emboss 40216



Stainless
Polish