

Dance, Dance Dance



Dance

IP-121 side chair

W506 × D519 × H764 × SH422

<u>Beech</u>	<u>Walnut</u>
580,00	690,00



Dance Dance

IP-122 armchair

W513 × D519 × H764 × SH422 × AH601

<u>Beech</u>	<u>Walnut</u>
690,00	800,00



Dance

IP-121F side chair

W506 × D519 × H764 × SH422

	<u>Upholstered</u>
F1	740,00
F2	800,00
L1	910,00
L2	980,00



Dance Dance


IP-122F armchair

W513 × D519 × H764 × SH422 × AH601


	<u>Upholstered</u>
F1	850,00
F2	910,00
L1	1.010,00
L2	1.080,00




Beech
Natural white




Beech
Snow white




Beech
Medium grey




Beech
Charcoal grey



Walnut
Clear



L1
Emboss 40202



L1
Emboss 40242



L1
Emboss 40243



L1
Emboss 40204



L1
Emboss 40205




L1
Emboss 40206




L1
Emboss 40209



L1
Emboss 40210



L1
Emboss 40215



L1
Emboss 40216



Stainless
Polish